

AMP V1 – ASSEMBLY GUIDE

This document will help you to build your module without any trouble! We will give the order in which the components should be placed on the boards to make your life easier during assembly.






If you want more information about how to build Eurorack modules and what tools you should have, go check our DIY electronics advice on our website: somethingmodular.fr

We also made an **online interactive BOM** so you can check components placement.

And again:

THANKS YOU FOR CHOOSING OUR KIT!! YOU'RE AWESOME!!

Now let's build this module, your module!

| RESISTORS | | | | |
|-----------|-------|-------------------------------------------------------------------------------------|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Qty | Value | Color | Code | Reference designator |
| 4 | 470 |  | Yellow, violet, black, black, brown | R20, R23, R35, R37 |
| 2 | 1k |  | Brown, black, black, brown, brown | R46, R47 |
| 2 | 1.2k |  | Brown, red, black, brown, brown | R30, R42 |
| 2 | 10k |  | Brown, black, black, red, brown | R15, R27 |
| 2 | 33k |  | Orange, orange, black, red, brown | R13, R24 |
| 29 | 100k |  | Brown, black, black, orange, brown | R1, R2, R3, R4, R5, R6, R7, R8, R9, R10, R11, R12, R14, R16, R17, R18, R19, R21, R22, R26, R28, R29, R32, R34, R36, R38, R40, R41, R44 |
| 2 | 330k |  | Orange, orange, black, orange, brown | R25, R39 |
| 4 | 1M |  | Brown, black, black, yellow, brown | R31, R33, R43, R45 |

AMP V1 – ASSEMBLY GUIDE

DIODES

Diodes are **Polarized!**

The black or white line on the diode must match the white line on the diode symbol on the Silkscreen.

| Qty | Value | Reference designator |
|-----|--------|----------------------|
| 3 | 1N5818 | D1, D2, D3 |

Integrated Circuits

ICs are oriented and so are sockets. Solder the sockets first, take care of orientation: the notch or dot on one end of the IC should match the silkscreen.

Before putting the ICs, **ground yourself** (you can touch the metal on your kitchen sink faucet).

Now, place the ICs, take care of orientation.

| Qty | Value | Reference designator |
|-----|-------------------|----------------------|
| 4 | TL074 | U2, U3, U4, U5 |
| 1 | V2164 (or AS2164) | U1 |

CAPACITORS

| Qty | Value | Code | Reference designator |
|-----|-------|------|-------------------------------------------|
| 4 | 100p | 101 | C13, C16, C17, C20 |
| 4 | 470p | 471 | C14, C15, C18, C19 |
| 10 | 100n | 104 | C3, C4, C5, C6, C7, C8, C9, C10, C11, C12 |

ELECTROLYTIC CAPACITORS

Electrolytic Capacitors are **Polarized!**

Mind the polarity : the long leg is the positive lead, negative lead is denoted by a white line.

| Qty | Value | Code | Voltage | Reference designator |
|-----|------------|------------|-------------|----------------------|
| 2 | 10 μ F | 10 μ F | ≥ 25 V | C1, C2 |

POWER CONNECTOR

This component should be soldered on the back of the PCB. Mind pin 1.

AMP V1 – ASSEMBLY GUIDE

FEMALE AND MALE PIN HEADERS

Place the female pin headers on the front side of board B, place the male pin headers on the back of board B. Put them inside each other.

Secure the spacer between board A and B.

Solder both female and male pin headers.

| Qty | Value | Reference designator |
|-----|------------------------|----------------------|
| 4 | 1x06 Female Pin Header | J20, J21, J22, J23 |
| 4 | 1x06 Male Pin Header | J10, J11, J12, J13 |

Now that you have solder your pin headers, unscrew one of the M3 spacer screw. Put Board B aside. We will start by soldering potentiometers and small jacks onto Board A.

READ THIS BEFORE SOLDERING ANYTHING:

Install potentiometers and mini-jacks onto board A without soldering. Now place the front panel, secure few components (top potentiometer and bottom jacks for example). Check for any mechanical stress on components, PCB or panel. If there is none then you can solder.

Remember to do this little routine every time you put front panel components, soldering without putting the front panel components first you risk to have hard time to align the components to the panel holes.

3.5mm Jack Sockets

| Qty | Value | Reference designator |
|-----|-----------|--------------------------------|
| 8 | PJ301M-12 | J2, J3, J4, J5, J6, J7, J8, J9 |

Potentiometers - ALPHA 9MM POTS

| Qty | Value | Reference designator |
|-----|-------------|----------------------|
| 4 | 100k linear | RV1, RV2, RV3, RV4 |

Now secure again the M3 spacer between Board A and B. Place the LEDs on the PCB. The shortest leg is the **negative side of the LED**. Put back the panel as you did before. Adjust the LED on the front panel and now you can solder.

AMP V1 – ASSEMBLY GUIDE

| LED 3mm | | |
|---------|-------|----------------------|
| Qty | Value | Reference designator |
| 2 | Red | D4, D5 |

Now you can secure every jacks and pots nuts. Once you are done. Put the potentiometer knobs on.

CONGRATULATION, you've just finished building your new module !

FIRST POWER UP TEST :

Before powering up your module, use a multimeter to check that there is no short between +12V, -12V and Ground rails.

Now you can power up your module: Connect the power ribbon cable (the red wire on the power ribbon cable corresponds to -12V) and **Enjoy!**

YOU'RE READY TO ROLL ! ENJOY YOUR NEW MODULE !